


إعداد رواتر Netgear D500



Configuring the Internet Connection

You are not yet connected to the Internet.

Do you want NETGEAR Genie to help?

- Yes
- No, I want to configure the Internet connection myself.
- I have saved the router settings in a file and I want to restore the router to those settings.

Next

No نختار
ثم نضغط Next

From www.routerlogin.net

Configuring the Internet connection requires networking experience.
Are you sure?

OK

Cancel

Configuring the Internet Connection

You are not yet connected to the Internet.

Do you want NETGEAR Genie to help?

No, I want to configure the Internet connection myself.

I have saved the router settings in a file and I want to restore the router to those settings.

OK نختار



مزود خدمة الإنترنت



BASIC 1

ADVANCED

- Home
- xDSL**
- Internet
- Wireless
- Attached Devices

xDSL Setup

2

Physical WAN Type

ADSL2+

DSL Mode

Auto

Apply

WAN

PVC Settings

Enable This Interface

Multiplexing Method

VPI

VCI

Apply

نختار LLC-BASED

VPI: 8

VCI: 35

LLC-BASED

8

35

ثم نضغط Apply



Internet Setup

Test

Cancel

Apply

8

Does your Internet connection require a login?

 Yes 1 No

Encapsulation 2

PPPoE(PPP over Ethernet)

Login 3

نكتب اسم المستخدم هنا

Password 4

نكتب كلمة السر هنا

Service Name (If Required)

نكتب AYA

Connection Mode

Always On

Idle Timeout (In Minutes)

0

Internet IP Address 6

 Get Dynamically from ISP Use Static IP Address

IP Address

10 . 138 . 221 . 205

Domain Name Server (DNS) Address 7

 Get Automatically from ISP Use These DNS Servers

مزود خدمة الإنترنت

- ADVANCED Home
- Setup Wizard
- Setup
- xDSL Setup
- Internet Setup
- Wireless Setup
- WAN Setup
- LAN Setup
- Administration
- Advanced Setup

Congratulations!

You are successfully connected to the Internet.

This router is preset with the following unique wireless network name (SSID) and network key_(password)

Wireless Network Name (SSID): NETGEAR78
Wireless Security Mode: WPA2-PSK [AES]
Wireless Network Key_(Password) : deeplotus204

Print this

Take me to the Internet

في حال ظهور هذه الصفحة
هذا يعني أن الاعدادات صحيحة



إعدادات الشبكة اللاسلكية WIFI

NETGEAR Router D500 x

Not secure | www.routerlogin.net/index.htm

NETGEAR genie D500

Router Firmware Version V1.0.0.23_1.0.1PE

Logout

Auto

BASIC ADVANCED

Home

xDSL

Internet

Wireless

Attached Devices

Wireless Settings

نضغط بالأخير Apply

إذا اردنا الشبكة غير مخفية

Cancel Apply

اسم الشبكة

اسم الشبكة

Region: Asia

Channel: Auto

Mode: Up to 150 Mbps

Enable SSID Broadcast

Name (SSID):

Region:

Channel:

Mode:

Security Options

None

WPA2-PSK [AES]

WPA-PSK [TKIP] + WPA2-PSK [AES]

WPA/WPA2 Enterprise

Security Options (WPA2-PSK)

Passphrase : كلمة السر (8-63 characters or 64 hex digits)

aya.SY

مزود خدمة الإنترنت

تعديل الـ MTU

The screenshot shows the NETGEAR D500 router's configuration interface. The browser address bar displays "www.routerlogin.net/adv_index.htm". The page title is "NETGEAR genie D500". The router firmware version is "V1.0.0.23_1.0.1PE". The "ADVANCED" tab is selected, and the "WAN Setup" page is open. The "MTU Size (in bytes)" field is set to "1442". The "Apply" button is highlighted. The "WAN Preference" is set to "Must use DSL WAN". The "Use port 2 as" is set to "LAN". The "MTU Size (in bytes)" field is highlighted with a green circle and the number "4". The "Apply" button is highlighted with a green circle and the number "5". The "Setup" button in the left sidebar is highlighted with a green circle and the number "2". The "WAN Setup" button in the left sidebar is highlighted with a green circle and the number "3". The "ADVANCED" tab is highlighted with a green circle and the number "1".

NETGEAR genie[®]
D500

Router Firmware Version
V1.0.0.23_1.0.1PE

Logout

Auto

1

2

3

4

5

Cancel

Apply

WAN Preference: Must use DSL WAN

Use port 2 as: LAN

10

MTU Size (in bytes): 1442

NAT Filtering: Secured

مزود خدمة الإنترنت

عرض قيم التشويش على الخط الأرضي SNR

NETGEAR Router D500 x

Not secure | www.routerlogin.net/adv_index.htm

NETGEAR genie D500

BASIC **ADVANCED** 1

ADVANCED Home 2

Setup Wizard

- ▶ Setup
- ▶ Administration

[Router Status](#)
[Attached Devices](#)
[Backup Settings](#)
[Set Password](#)
[Firmware Update](#)

▶ **Advanced Setup**

Hardware Version	D500-100PES-A	MAC Address	A4:2B:8C:22:FB:09
Firmware Version	V1.0.0.23_1.0.1PE	IP Address	10.138.221.205
GUI Language Version	V1.0.0.23_1.0.1	Connection	PPPoE

LAN Port

MAC Address	A4:2B:8C:22:FB:08	IP Subnet Mask	255.255.255.255
IP Address	192.168.1.1	Gateway IP Address	82.137.200.6
DHCP Server	Enable	Domain Name Server	82.137.200.26 82.137.200.23

Reboot **Show Statistics** **Connection Status**

Modem

xDSL Firmware Version	4926e811
Modem Status	Link Up
DownStream Connection Speed	2047 kbps
UpStream Connection Speed	510 kbps
VPI	8
VCI	35

Modem Statistics

Wireless Settings

Name (SSID)	
Region	Asia
Channel	1(P) + 5(S)
Wireless AP	On
Broadcast Name	On

HELP & SUPPORT Documentation | Online Support | Router FAQ

xDSL Line Status

Mode	--
Latency	Interleave
Trellis Coding	1
Status	SHOWTIME.L0
Power Level	L0
Uptime	0 0:32:44

	Downstream	Upstream
SNR Margin (dB)	30.4	24.9
Attenuation (dB)	12	10
Output Power (dBm)	8	12.5
Attainable Rate (Kbps)	22684 kbps	876 kbps
Rate (kbps)	2047 kbps	510 kbps
K (number of bytes in DMT frame)	55	27
R (number of check bytes in RS code word)	12	10
S (RS code word size in DMT frame)	0	3
D (interleave depth)	32	8
Delay (msec)	6	6
FEC	0	65501
CRC	0	0
Total ES	0	0
Total SES	0	0
Total UAS	0	0
Total LOSS	0	0