

D-Link



مزود خدمة الإنترنت

DSL-2740U

SETUP

ADVANCED

MAINTENANCE

STATUS

HELP

Wizard

Local Network

Internet Setup

Wireless Setup

Time and Date

SETTING UP YOUR INTERNET

There are two ways to set up your Internet connection. You can use the Web-based Internet Connection Setup Wizard or you can manually configure the connection.

Please make sure you have your ISP's connection settings first if you choose manual setup.

INTERNET CONNECTION WIZARD

You can use this wizard for assistance and quick connection of your new D-Link Router to the Internet. You will be presented with step-by-step instructions in order to get your Internet connection up and running. Click the button below to begin.

[Setup Wizard](#)

Note: Before launching the wizard, please ensure you have correctly followed the steps outlined in the Quick Installation Guide included with the router.

Helpful Hints...

First time users are recommended to run the **Setup Wizard**. Click the **Setup Wizard** button and you will be guided step by step through the process of setting up your ADSL connection.

If you consider yourself an advanced user or have configured a router before, click **Setup->Internet Setup** to input all the settings manually.

[More...](#)

D-Link



مزود خدمة الإنترنت

WELCOME TO D-LINK SETUP WIZARD

This wizard will guide you through a step-by-step process to configure your new D-Link router and connect to the Internet.

- **Step 1** : Interface Type
- **Step 2** : Change Device Login Password
- **Step 3** : Set Time and Date
- **Step 4** : Setup Internet Connection
- **Step 5** : Configure Wireless Network
- **Step 6** : Completed and Apply



مزود خدمة الإنترنت

STEP 1: SELECT WAN INTERFACE TYPE → 2 → 3 → 4 → 5 → 6

Please select which WAN interface to use: DSL or Ethernet WAN.

Select Interface Type: DSL WAN Ethernet WAN

Note: The router will restart if you change from DSL to ETH or ETH to DSL. Once done restarting, you can just continue where you left of.

D-Link



مزود خدمة الإنترنت

1 → STEP 2: CHANGE DEVICE LOGIN PASSWORD → 3 → 4 → 5 → 6

To help secure your network, D-Link recommends that you should choose a new password. If you do not wish to choose a new password now, just click "Skip" to continue. Click "Next" to proceed to next step.

Current Password : New Password : Confirm Password :

D-Link

مزود خدمة الإنترنت

1 → 2 → STEP 3: SET TIME AND DATE → 4 → 5 → 6

The Time Configuration option allows you to configure, update, and maintain the correct time on the internal system clock. From this section you can set the time zone that you are in and set the NTP (Network Time Protocol) Server. Daylight Saving can also be configured to automatically adjust the time when needed.

SYSTEM TIME**System time:** Sun Jan 1 1:25:52 2012**Time Zone:** (GMT+03:00) Baghdad ▼**DayLight:** LocalTIME ▼**Mode:** Copy Computer time ▼

Back

Next

Cancel

D-Link

مزود خدمة الإنترنت

1 → 2 → 3 → STEP 4: SETUP INTERNET CONNECTION → 5 → 6

Please select your Country and ISP (Internet Service Provider) from the list below. If your Country or ISP is not in the list, please select "Others".

Country : Syria ▼
Internet Service Provider : AYA ▼
Protocol : PPPoE ▼
Connection Type : LLC ▼
VPI : 8 (0-255)
VCI : 35 (32-65535)

PPPoE

Please enter your Username and Password as provided by your ISP (Internet Service Provider). Please enter the information exactly as shown taking note of upper and lower cases. Click "Next" to continue.

Username : -----@aya.sy
Password : *****
Confirm Password : *****

Back

Next

Cancel

Your wireless network is enabled by default. You can simply uncheck it to disable it and click "Next" to skip configuration of wireless network.



مزود خدمة الإنترنت

Enable Your Wireless Network

Your wireless network needs a name so it can be easily recognized by wireless clients. For security purposes, it is highly recommended to change the pre-configured network name.

Wireless Network Name (SSID) : (1~32 characters)

Select "Visible" to publish your wireless network and SSID can be found by wireless clients, or select "Invisible" to hide your wireless network so that users need to manually enter SSID in order to connect to your wireless network.

Visibility Status :

ظاهره

Visible Invisible

مخفية

In order to protect your network from hackers and unauthorized users, it is highly recommended you choose one of the following wireless network security settings.

Security Level :

None

WEP

WPA-PSK

نمط الحماية

WPA2-PSK

Security Mode: WPA-PSK

Select this option if your wireless adapters support WPA-PSK.

Now, please enter your wireless security key.

WPA2 Pre-Shared Key :

(8-63 characters, such as a~z, A~Z, or 0~9, i.e. "%Fortress123&")

Note: You will need to enter the same key here into your wireless clients in order to enable proper wireless connection.

Back

Next

Cancel




مزود خدمة الإنترنت

1 → 2 → 3 → 4 → 5 → STEP 6: COMPLETED AND APPLY

Setup complete. Click "Back" to review or modify settings. Click "Apply" to apply current settings.

If your Internet connection does not work after apply, you can try the Setup Wizard again with alternative settings or use Manual Setup instead if you have your Internet connection details as provided by your ISP.

SETUP SUMMARY

Below is a detailed summary of your settings. Please print this page  or write the information on a piece of paper, so you can configure the correct settings on your wireless client adapters.

Time Settings :	Copy from Computer
VPI / VCI :	8/35
Protocol :	PPPoE
Connection Type :	LLC
Username :	Karim.KH@aya.sy
Password :	123456
Wireless Network :	Enabled
Wireless Network Name (SSID) :	Al-Khayat
Visibility Status :	Visible
Encryption :	WPA2-PSK/AES (also known as WPA2 Personal)
Pre-Shared Key :	%Fortress123&

Back

Apply

Cancel

DSL-2740U	SETUP	ADVANCED	MAINTENANCE	STATUS	HELP
Wizard	SETTING UP YOUR INTERNET				Helpful Hints... First time users are recommended to run the Setup Wizard . Click the Setup Wizard button and you will be guided step by step through the process of setting up your ADSL connection. If you consider yourself an advanced user or have configured a router before, click Setup > Internet Setup to input all the settings manually. More...
Local Network	There are two ways to set up your Internet connection. You can use the Web-based Internet Setup Wizard or you can manually configure the connection.				
Internet Setup	Channel Config	You must have your ISP's connection settings first if you choose manual setup.			
Wireless Setup	ATM Settings	CONNECTION WIZARD			
Time and Date	ADSL Settings	You can use this wizard for assistance and quick connection of your new D-Link Router to the Internet. You will be presented with step-by-step instructions in order to get your Internet connection up and running. Click the button below to begin.			
	PVC Auto Search	<input type="button" value="Setup Wizard"/>			
		Note: Before launching the wizard, please ensure you have correctly followed the steps outlined in the Quick Installation Guide included with the router.			
BROADBAND					

- DSL-2740U
- Wizard
- Local Network
- Internet Setup
- Wireless Setup
- Time and Date

SETUP **ADVANCED** MAINTENANCE STATUS HELP

CHANNEL CONFIGURATION

This page is used to configure the parameters for the channel operation modes of your ADSL Modem/Router. Note : When connect type of PPPoE and PPPoA only is "Manual", the "Connect" and "Disconnect" button will be enable.

WAN PHYSICAL TYPE

WAN Physical Type: ADSL WAN Ethernet WAN

DEFAULT ROUTE SELECTION

Default Route Selection: Auto Specified

CHANNEL CONFIGURATION

VPI: VCI:
Channel Mode:
802.1q: Disable Enable
Encapsulation: LLC VC-Mux
Enable NAP: Enable IGMP:
VLAN ID(1-4095):

PPP Settings: User Name: Password:
Type: Idle Time (min):

WAN IP Settings: Type: Fixed IP DHCP
Local IP Address: Remote IP Address:
Netmask:

Default

Helpful Hints...
When configuring the router to access the Internet, be sure to choose the correct **Channel Mode** from the list below.
Please take care when entering your **username** and **password** as these are case sensitive. The majority of connection issues are caused by incorrect **username** or **password** combinations.
Note: Be sure to restart the router for the new Internet Setting to take effect.
[More...](#)



PPP Settings: User Name: Password:

Type: Idle Time (min):

WAN IP Settings: Type: Fixed IP DHCP

Local IP Address: Remote IP Address:

Netmask:

Default Route: Disable Enable Auto

Unnumbered

-

CURRENT ATM VC TABLE:

Select	Inf	Mode	VPI	VCI	Encap	NAPT	IGMP	DRo	IP A	Rem	NetM	User	Statu	Edit
ct		e			p	T	P	ute	ddr	ote I	ask	Nam	s	
<input type="radio"/>	ppp oe1	PPP oE	0	50	LLC	On	Off	Off	0.0. 0.0	0.0. 0.0	255. 255. 255. 255		Dow n	
<input type="radio"/>	ppp oe2	PPP oE	8	35	LLC	On	Off	On	90.1 53.2 30.7 4	10.1 0.10. 5	255. 255. 255. 255	@aya.sy	Up	



Wizard

Local Network

Internet Setup

Wireless Setup

Time and Date

PPP INTERFACE - MODIFY

This page is used for advanced PPP interface configuration.

PPP INTERFACE

Protocol:	PPPoE
ATM VCC:	8/35
Login Name:	<input type="text"/>
Password:	<input type="password" value="*****"/>
Authentication Method:	AUTO ▾
Connection Type:	Continuous ▾
Idle Time (s):	<input type="text" value="0"/>
Bridge:	<input type="radio"/> Bridged Ethernet (Transparent Bridging) <input type="radio"/> Bridged PPPoE (implies Bridged Ethernet) <input checked="" type="radio"/> Disable Bridge
AC-Name:	<input type="text"/>
Service-Name:	<input type="text"/>
802.1q:	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
VLAN ID(1-4095):	<input type="text" value="0"/>
MTU (1-1500):	<input type="text" value="1492"/>
Static IP:	<input type="text"/>
Source Mac address:	<input type="text" value="A0:AB:1B:19:B2:41"/> (ex:00:E0:86:71:05:02)
	<input type="button" value="MACCLONE"/>



مزود خدمة الإنترنت

Device Info

Wireless Clients

DHCP Clients

ADSL Driver

Statistics

Route Info

ADSL CONFIGURATION

This page shows the setting of the ADSL Router.

ADSL

Adsl Line Status	SHOWTIME.L0
Adsl Mode	G992.5
Channel Mode	Interleave
Up Stream	509 kbps
Down Stream	2047 kbps
Attenuation Down Stream	26
Attenuation Up Stream	17
SNR Margin Down Stream	30.5
SNR Margin Up Stream	25.0
Vendor ID	RETK
Firmware Version	4926d722
CRC Errors	0
Up Stream BER	0e-7
Down Stream BER	0e-7
Up Output Power	12
Down Output Power	15
ES	0
SES	0
UAS	0

Retrain

Refresh

Helpful Hints...

Displays ADSL setting.

[More...](#)

مزود خدمة الإنترنت