

Wizard

Local Network

Internet Setup

Wireless Setup

Time and Date

SETTING UP YOUR INTERNET

There are two ways to set up your Internet connection. You can use the Web-based Internet Connection Setup Wizard or you can manually configure the connection.

Please make sure you have your ISP's connection settings first if you choose manual setup.

INTERNET CONNECTION WIZARD

You can use this wizard for assistance and quick connection of your new D-Link Router to the Internet. You will be presented with step-by-step instructions in order to get your Internet connection up and running. Click the button below to begin.

Setup Wizard

Note: Before launching the wizard, please ensure you have correctly followed the steps outlined in the Quick Installation Guide included with the router.

Helpful Hints...

First time users are recommended to run the **Setup Wizard**. Click the **Setup Wizard** button and you will be guided step by step through the process of setting up your ADSL connection.

If you consider yourself an advanced user or have configured a router before, click **Setup->Internet Setup** to input all the settings manually.

More...

1 > STEP 2: SET TIME AND DATE > 3 > 4 > 5

The Time Configuration option allows you to configure, update, and maintain the correct time on the internal system clock. From this section you can set the time zone that you are in and set the NTP (Network Time Protocol) Server. Daylight Saving can also be configured to automatically adjust the time when needed.

SYSTEM TIME

System time: Sun Jan 1 0:2:32 2012

Time Zone: (GMT-00:00) Casablanca, Monrovia

DayLight: LocalTIME

Mode: Copy Computer time

Back

Next

Cancel




مزود خدمة الإنترنت

STEP 1: CHANGE DEVICE LOGIN PASSWORD > 2 > 3 > 4 > 5

To help secure your network, D-Link recommends that you should choose a new password. If you do not wish to choose a new password now, just click "Skip" to continue. Click "Next" to proceed to next step.

Current Password :

New Password :

Confirm Password :

Back Next **Skip** Cancel




مزود خدمة الإنترنت

 1 — 2 — **STEP 3: SETUP INTERNET CONNECTION** — 4 — 5

Please select your WAN Physical Type.

WAN Physical Type : DSL WAN ▼

ISP

Please select your Country and ISP (Internet Service Provider) from the list below. If your Country or ISP is not in the list, please select "Others".

Country : Syria ▼


Internet Service Provider : AYA ▼

Protocol : PPPoE ▼

Connection Type : LLC ▼

VPI : 8 (0-255)

VCI : 35 (32-65535)


PPPoE

Please enter your Username and Password as provided by your ISP (Internet Service Provider). Please enter the information exactly as shown taking note of upper and lower cases. Click "Next" to continue.

Username : username@aya.sy

Password : *****

Confirm Password : *****




Back **Next** Cancel

1 — 2 — 3 — STEP 4: CONFIGURE WIRELESS NETWORK — 5

Your wireless network is enabled by default. You can simply uncheck it to disable it and click "Next" to skip configuration of wireless network.

 Enable Your Wireless Network

Your wireless network needs a name so it can be easily recognized by wireless clients. For security purposes, it is highly recommended to change the pre-configured network name.

Wireless Network Name (SSID) : (1~32 characters) 

Select "Visible" to publish your wireless network and SSID can be found by wireless clients, or select "Invisible" to hide your wireless network so that users need to manually enter SSID in order to connect to your wireless network.

Visibility Status : Visible Invisible

In order to protect your network from hackers and unauthorized users, it is highly recommended you choose one of the following wireless network security settings. 

Security Level :


None WEP WPA-PSK WPA2-PSK

Security Mode: WPA-PSK

Select this option if your wireless adapters support WPA-PSK.

Now, please enter your wireless security key.

WPA2 Pre-Shared Key :



(8-63 characters, such as a~z, A~Z, or 0~9, i.e. '%Fortress123&')

Note: You will need to enter the same key here into your wireless clients in order to enable proper wireless connection.

1 — 2 — 3 — 4 — **STEP 5: COMPLETED AND APPLY**

Setup complete. Click "Back" to review or modify settings. Click "Apply" to apply current settings.

If your Internet connection does not work after apply, you can try the Setup Wizard again with alternative settings or use Manual Setup instead if you have your Internet connection details as provided by your ISP.

SETUP SUMMARY

Below is a detailed summary of your settings. Please print this page out, or write the information on a piece of paper, so you can configure the correct settings on your wireless client adapters.

Modem Password :	admin1
Time Settings :	Copy from Computer
WAN Physical Type :	DSL WAN
VPI / VCI :	8/35
Protocol :	PPPoE
Connection Type :	LLC
Username :	qseemoh@tarassul.sy
Password :	
Wireless Network :	Enabled
Wireless Network Name (SSID) :	Qusai
Visibility Status :	Invisible
Encryption :	WPA2-PSK/AES (also known as WPA2 Personal)
Pre-Shared Key :	p@ssw0rd1994qusai

Back **Apply** Cancel

Authentication required

http://192.168.1.1
Your connection to this site is not private



Username

Password



DSL-124 // SETUP ADVANCED MAINTENANCE STATUS HELP

Wizard

Local Network

Internet Setup

Wireless Setup

Time and Date

SETTING UP YOUR INTERNET

There are two ways to set up your Internet connection. You can use the Web-based Internet Setup Wizard or you can manually configure the connection.

You must first have your ISP's connection settings first if you choose manual setup.

CONNECTION WIZARD

You can use this wizard for assistance and quick connection of your new D-Link Router to the Internet. You will be presented with step-by-step instructions in order to get your Internet connection up and running. Click the button below to begin.

Note: Before launching the wizard, please ensure you have correctly followed the steps outlined in the Quick Installation Guide included with the router.

Helpful Hints...

First time users are recommended to run the Setup Wizard. Click the **Setup Wizard** button and you will be guided step by step through the process of setting up your ADSL connection.

If you consider yourself an advanced user or have configured a router before, click **Setup > Internet Setup** to input all the settings manually.

[More...](#)

BROADBAND

CHANNEL CONFIGURATION

VPI: VCI:

Encapsulation: LLC VC-Mux

Channel Mode:

Enable NAPT: Enable IGMP:

VLAN: Disable Enable

VLAN ID(1-4095):

PPP Settings: User Name: Password:

Type: Idle Time (min):


WAN IP Settings: Type: Fixed IP DHCP

Local IP Address: Remote IP Address:

Netmask:


Default Route: Disable Enable Auto

Unnumbered:



مزود خدمة الإنترنت

CURRENT WAN TABLE:

Select	Inf	Mode	VPI	VCI	Enca p	NAP T	IGM P	DRou te	IP A ddr	Rem ote I p	NetM ask	User Nam e	Statu s	Edit
<input type="radio"/>	pppo e1	PPPo E	8	35	LLC	On	Off	On	10.1 21.2 8.22 7	82.1 37.2 00.3	255. 255. 255. 255	qsee moh @tar assu l.sy	Up	

password combinations.

Note: Be sure to restart the router for the new Internet Setting to take effect.

[More...](#)

PPP INTERFACE - MODIFY

This page is used for advanced PPP interface configuration.

PPP INTERFACE

Protocol: PPPoE

ATM VCC: 8/35

Login Name: user@aya.sy

Password: ****

Authentication Method: AUTO ▼

Connection Type: Continuous ▼

Idle Time (s): 0

- Bridge:**
- Bridged Ethernet (Transparent Bridging)
 - Bridged PPPoE (implies Bridged Ethernet)
 - Disable Bridge

AC-Name:

Service-Name:

MTU (1-1500): 1492

Static IP:

Source Mac address: 80:26:89:C0:13:6B (ex:00:E0:86:71:05:02)

MACCLONE

Apply Changes

Return

Undo

Device Info

Wireless Clients

DHCP Clients

ADSL Driver

Statistics

Route Info

ADSL CONFIGURATION

This page shows the setting of the ADSL Router.

ADSL

Adsl Line Status	SHOWTIME.LO
Adsl Mode	G992.5
Channel Mode	Interleave
Up Stream	509 kbps
Down Stream	2047 kbps
Attenuation Down Stream	42
Attenuation Up Stream	27
SNR Margin Down Stream	15.1
SNR Margin Up Stream	19.8
Vendor ID	RETK
Firmware Version	4926e811
CRC Errors	7
Up Stream BER	0e-7
Down Stream BER	1e-7
Up Output Power	1
Down Output Power	10
ES	4
SES	0
UAS	0

Retrain

Refresh

Helpful Hints...

Displays ADSL setting.

More...