

WLAN

Auto PVC

ATM

ADSL

LAN

WLAN



WAN Physical Type:

ADSL WAN Ethernet WAN

Default Route Selection:

Auto Specified

VPI:

0

VCI:

32

Encapsulation:

LLC

VC-Mux

Channel Mode:

PPPoE

Enable NAPT:

Enable IGMP:

IP Protocol:

Ipv4/Ipv6

PPP Settings:

User Name:

ayatv

Password:

iptvaya

Type:

Continuous

Idle Time (min):

WAN IP Settings:

Type:

Fixed IP

DHCP

IP Address:

ISP Gateway:

WAN IP Settings:			
Type:	<input type="radio"/> Fixed IP	<input type="radio"/> DHCP	
IP Address:	<input type="text"/>	ISP Gateway:	<input type="text"/>
Subnet Mask:	<input type="text"/>		
Primary DNS Server:	<input type="text"/>	Secondary DNS Server:	<input type="text"/>
Default Route:	<input type="radio"/> Disable	<input type="radio"/> Enable	<input type="radio"/> Auto
Unnumbered:	<input type="checkbox"/>		

9

IPv6 WAN Setting:	
Address Mode:	<input type="text" value="SlAAC"/>



IPv6 DNS Mode:	<input type="text" value="Auto"/>
----------------	-----------------------------------

DHCPv6 Mode:	<input type="text" value="Auto"/>
Request DHCPv6 PD:	<input checked="" type="checkbox"/>

10

[Connect](#) [Disconnect](#) [Add](#) [Modify](#) [Delete](#) [Undo](#) [Refresh](#)

WAN Interface Table:

- WAN
- LAN
- LAN
 - LAN
 - DHCP
 - DHCP Static
 - LAN IPv6
- WLAN



LAN Interface Setup

This page is used to configure the LAN interface of your ADSL Router. Here you may change the setting for IP address, subnet mask, etc..

Interface Name:	Ethernet1
IP Address:	<input type="text" value="192.168.1.1"/>
Subnet Mask:	<input type="text" value="255.255.255.0"/>
<input type="checkbox"/> Secondary IP	
IGMP Snooping:	<input type="radio"/> Disable <input checked="" type="radio"/> Enable

11

Apply Changes

LAN Port:	<input type="text" value=""/>
Link Speed/Duplex Mode:	<input type="text" value=""/>

Modify

ETHERNET Status Table:

Select	Port	Link Mode
<input type="radio"/>	LAN1	AUTO Negotiation

[Status](#)
[Quick Start](#)
[Setup](#)
[Advanced](#)
[Service](#)
[Firewall](#)
[Maintenance](#)
[Route](#)
[Static Route](#)
[IPv6 Static Route](#)
[RIP](#)
[NAT](#)
[QoS](#)
[CWMP](#)
[Port Mapping](#)
[Others](#)


Routing Configuration

This page is used to configure the routing information. Here you can add/delete IP routes.

Enable:



12

Destination:

Subnet Mask:

13

Next Hop:

Metric:

14

Interface:

15

[Add Route](#)
[Update](#)
[Delete Selected](#)
[Show Routes](#)

⚙ Static Route Table:

Select	State	Destination	Subnet Mask	NextHop	Metric	Itf
--------	-------	-------------	-------------	---------	--------	-----